



	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
A	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
B	A	B	C	D	E	F	G	H	I	J	CH5	CH6	DSK	PIP	C-KEY	CUT	TAKE	REC	ENG	PROD
C	K	L	M	N	O	P	Q	R	S	T	REPLAY	RET1	RET2	KEY ON	AUTO TAKE					
D	U	V	W	X	Y	Z	POWER	ON OFF	ON	OFF		USER A	USER B	USER C	USER D	USER E	USER F	USER G	USER H	USER I
E	OK		Auto	Enter	Start	STOP	OPEN	CLOSE	Exit	Move	USER J								M-1	
F	SET	Reset	Light	Alarm	Menu	Next	Back	Delete	Motor	Save										
G	Up	Down	Right	Left	Test	End	Insert	Lock	Print	+/-							IN PORT	SOS		TC
H	ESC	BC.	HOME	Health	D-LED 2	OC GENIE	VIDEO INPUT	clr CMOS	Green Power	Save OK	P1	P2	P3	P4	P5	D C	A C			TURBO
I				F1	F2	F3	F4	F5	F6	F7	SEEK	TRACK	RNA	AS/RPT	Select					
J	F8	F9	F10	F11	F12	F13	F14	IN 1	IN 2	IN 3						ON AIR		D.	M.	
K	IN 4	IN 5	IN 6											HDMI	VGA					
L	+	-	x	÷	=	↑	→	▲	▶	▶		MON	ITEM	C/S	GAS	PUMP ON/OFF	PURGE	R/HR	PART	IOD
M							↑	→	↑	→	FILT	LO RANGE	MID RANGE	MID	HI RANGE	GPD	EFF LEVEL			
N	↑	→	↑	◀	▶	◀	▶	◀	▶	◀	▶			HOUR	MIN	ZOOM IN	ZOOM OUT	FAR	NEAR	Fn
O											ANN.	MIC OFF								
P							Config.	TIME LINE	ME1	ME2									write	save
Q	ME3	ME4	BOND 3D DVE1	BOND 3D DVE2	BUS COLOR	ME BUTTON LINK	*	INSERT	WIPE		PC CONTRON	Sel	track	pen SUFF	send	EQ	plugin	instr	group	read off
R	◀	ALL		VP		COPY		RECORD MODE	↑		latch	trim	cmp all	control	option	shuttle	scrub	name values	smpt beats	shift
S			MUTE								zoom	DAW	marker	nudge	click	drop	replace	solo	undo	flip
T		<i>hold</i>	<i>group</i>	<i>m1</i>	<i>m2</i>	<i>m3</i>	<i>m4</i>	<i>m5</i>	<i>t1</i>	<i>t2</i>	assign	<	FUNCTION	CANCEL	5/6	SOLO	TV	TV1	TV2	HDMI1
U	<i>s1</i>	<i>s2</i>	<i>chair</i>	<i>undo</i>	<i>redo</i>	<i>touch</i>	<i>store</i>	<i>recall</i>	<i>e1</i>	<i>e2</i>	HDMI2	DVD	VIDEO	SAT	CBL	AUX	AUX1	AUX2	PROJ	PROJ1
V	<i>e3</i>	<i>e4</i>				CLEAR	CROSS WIND	AMMO TEMP	BARO PERSS	AIR TEMP	PROJ2	DOC	PC	PC1	PC2	YPbPr	VCR	VTC	VGA1	VGA2
W	BORE-SIGHT	CANT	LEAD	RANGE	MRS	ZERO	TEST	UD	LR		SCRN UP	SCRN DN	INPUT			#		START STOP	CMOS	Level bypass
X	ID	Disp	MF	CALL	.	BAND	SETUP	MODE	LINK	FUNC.	Parallel output	Phase left CH	insert	Mono	VERIFY	PROG	BLANK	ERASE	DEV	CT
Y	SHIFT					DEL						ECS	JOB	[v]						
Z				RUN	2D	3D	CH1	CH2	CH3	CH4	AC 電源	SPACE					OUTPUT FADE	PAGE	KEY SEL	DSK SEL

- TACT SWITCH
- PUSH BUTTON SWITCH
- LED TOUCH SENSOR SWITCH
- 5 DIRECTION NAVIGATION SWITCH WITH LED
- MEMBRANE SWITCH
- LED LIGHT BAR
- SLIDE SWITCH
- ROTARY SWITCH
- ROCKER SWITCH
- DETECT SWITCH
- ENCODER
- INTERRUPTER
- MINIATURE MICRO SWITCH
- TELEPHONE HOOK SWITCH
- DOOR SWITCH
- MINI SIZE SOCKET
- KNOB
- CAP SYMBOL



- TACT SWITCH
- PUSH BUTTON SWITCH
- LED TOUCH SENSOR SWITCH
- 5 DIRECTION NAVIGATION SWITCH WITH LED
- MEMBRANE SWITCH
- LED LIGHT BAR
- SLIDE SWITCH
- ROTARY SWITCH
- ROCKER SWITCH
- DETECT SWITCH
- ENCODER
- INTERRUPTER
- MINIATURE MICRO SWITCH
- TELEPHONE HOOK SWITCH
- DOOR SWITCH
- MINI SIZE SOCKET
- KNOB
- CAP SYMBOL

	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39			
A										MIX	SEL	MAIL ALARM		HDCP	TIME		HDCP INFL	PATT ERN		EXIT			
B	SYSTEM	gag		PLAY	STOP		TV	Shift	BG	FTB	FS	ME1	ME2	ME3	ME4	INV	SOFT	FREEZE	LOGO 1	LOGO 2			
C	PIP1	PIP2	DSK1	DSK2	M1	M2	M3	M4	M5	M6	M7	M8	ENT	CLR	MTR	F RST	PAB	OCC	DCC	測站			
D	DMO	EMR						CLOSE POLL	I/O	Out 1	Out 2	Out 3	Pro Tools	Logic	Ableton	Cubase	Nuendo	Studio One	CD	Idevice			
E	Ref#	Mac	Adam	Genelec	Dynaudio	Barefoot	APS	Focal	Neumann	COAX	Equator	Sveda	NS-10	Nearfield	Main	Mini	Midfield	Fullrange	SUB	Centurion			
F	Talkback	Talkback mode	Scene 1	Scene 2	Scene 3	Scene 4	Scene 5	Scene 6	Scene 7	Scene 8	SET+	SET-		CAN RES					FLOW	NAVI MODE			
G		ONE CYCLE	TRAY CHANGE	STACK LINKAD	OVERRC AC	FRONT	SEND SHRT	STOP	INTIAL	PETRY	SKIP	RETURN	LEFT CONTACT	RIGHT CONTACT	ONLOCK	?	HELP			REAR			
H		ENGINE START	ENGINE STOP	Mosaic	Bypass	Select All									FREEZE	CTRL ENA	WHT BAL	GAIN	AWC ABC	SCENE	BANK	SAVE	AE
I	SPEED			ENGINE STARTSTOP	Auto Recall	高速	荷卸	休憩	待機	待機	待機	ON/OFF BUSINESS	Auto Run		Image ON/OFF	開機	開機	遮幕	電腦	筆電	視頻		
J	銀幕升	銀幕停	銀幕降	自動		ACO	CAPTURE	MAIN	INPUT	PGM	PVW	AUDIO	SPORT			IRKGD	CUT FILL	DSK1 TIE	DSK2 TIE	DIP			
K		ENGINE STAR			Coord	mR/HR	SAMP FLOW	HIGH RANGE	LOW RANGE						ON OFF								
L	DSK1 AUTO	DSK2 AUTO	ON AIR 1	ON AIR 2	KEY1	FTB		PARMS	WIPES	RATES				FOL+	FOL-	Repeat	Random		USB	KEY2			
M	Laptop	Mixer	PC	Cam 1	Cam 2	Cam 3	Cam 4	Computer	Camera 1	Camera 2	Camera 3	Camera 4	Polarity left ch.	Tannoy	B&W	Pods	Amphion	HiLo	Apollo	REAL LOUDI			
N	Nice & Calm	銀幕上	銀幕中	銀幕下	NEXT		VIEW	STBY	CTRL	LOCK	SOS (b=x)	USER J	FUEL	BACK SPACE	DIR	DATA	OUT	LOAD	KVM		高畫質		
O	1+	2+	3+	4+	1-	2-	3-	4-	1.2 system	3.4 system	Check			PIP	APPLE TV					SW	電腦 2		
P																							
Q																							
R																							
S																							
T																							
U																							
V																							
W																							
X																							
Y																							
Z																							